


DATA SHEET

PRESSURE SENSITIVE REGULATING UNLOADER



Brass Model: 7620



FEATURES

- Provides system pressure setting and protection for single gun (non-weep) and single pump installation.
- Compact size with auxiliary port for easy installation of gauge.
- Optional handle permits easy adjustments of pressure.
- Pressure sensitive feature permits wide range of flows and immediate pressure when gun opens.

SPECIFICATIONS

	U.S.	Metric
Flow Range	0.5 - 8.0 gpm	1.9 - 30 lpm
Pressure Range	100 - 3200 psi	6.9 - 220 bar
Maximum Temperature	195°F	90°C
Inlet Port, Male	3/8" BSPP(G)	3/8" BSPP(G)
Discharge Port, Female	3/8" BSPP(G)	3/8" BSPP(G)
By-pass Port, Female	3/8" BSPP(G)	3/8" BSPP(G)
Auxiliary Port, Female	1/4" BSPP(G)	1/4" BSPP(G)
Weight	1.3 lbs	0.59 kg
Dimensions	3.34 x 1.5 x 4.72"	85 x 38 x 120 mm

For Relief Valve version add .100 to unloader model number.

Read all CAUTIONS and WARNINGS before commencing service or operation of any high-pressure system

SELECTION

This pressure sensitive regulating unloader is designed for systems with single pumps, solenoid (gate) valves, nozzles. "Weep" guns are not recommended with this unloader.

This pressure sensitive regulating unloader should meet both the desired system flow (combined nozzle flow rate requirement) and the designed system pressure.

Notice: Operation below the minimum flow of the unloader causes the unloader to cycle. Operation above the maximum flows of the unloader causes premature unloader wear, cycling and prevents attaining desired system pressure.

INSTALLATION

This unloader operates properly when mounted in any direction, however, it is preferred to keep the plumbing to a minimum and the adjusting handle easily accessible. The best mounting location is directly on the pump discharge manifold head.

The inlet connection on this unloader is a 3/8" BSP(M) port and is located on the left side. Arrow and the word "IN" are cast into the body indicating the direction of flow. Liquid from the discharge of the manifold goes through the connection.

The discharge connection on this unloader is a 3/8" BSP(F) port and is located on the right side (hex end). An arrow and the word "OUT" is cast into the body indicating the direction of flow. Plumbing to the spray guns, solenoid (gate) valves or nozzles are connected here.

The by-pass connection on this unloader is a 3/8" BSP(F) port and is located on the bottom. An arrow and the word "BY PASS" is cast into the body indicating the direction of flow. By-pass liquid is directed out of this port and can be routed to a reservoir (preferred method), or to a drain or to the pump inlet.

The auxiliary connection on this unloader is a 1/4" BSP(F) port and is located on the side. A pressure gauge can be mounted to this port.

OPERATION

This pressure sensitive regulating unloader holds established system pressure in the discharge line when the trigger gun is closed or solenoid (gate) valve is closed or the nozzle is clogged, thus by-passing all unrequired flow. Squeezing the trigger gun or opening the solenoid (gate) valve will close the by-pass and return to established system pressure.

PRESSURE ADJUSTMENT

1. Setting and adjusting the unloader pressure must be done with the system "on".
2. Start the system with unloader backed off to the lowest pressure setting (counterclockwise direction).
3. Squeeze the trigger and read the pressure on the gauge at the pump.

Note: Do not read the pressure at the gun or nozzle.

4. If more pressure is desired, release the trigger, turn adjusting cap one quarter turn in clockwise direction.
5. Squeeze the trigger and read the pressure.
6. Repeat this process until desired system pressure is attained.
7. Once the desired system pressure is reached, stop turning the adjusting cap.

Note: Pressure is not set at the factory.

Notice: A minimum by-pass flow of 5% of the unloader rated flow capacity is required for proper unloader performance. If the entire output is directed through the nozzle (zero by-pass) the "cushioning" feature of the by-pass liquid is eliminated and the unloader can wear or malfunction prematurely.

8. If desired system pressure cannot be reached, review TROUBLESHOOTING chart.
9. When servicing existing systems, follow adjustment procedures as stated above.


Note: Do not adjust unloader pressure setting to compensate for a worn nozzle. Check the nozzle as part of the regular maintenance and replace if worn.

Note: A secondary pressure safety relief device (i.e. pop-off valve, safety valve) should be used along with this pressure sensitive regulating unloader. Final adjustment for the relief valve should relieve at 200 psi above the system operating pressure.

Note: By removing the check valve and spring, this unloader can function as a secondary relief valve.

TYPICAL UNLOADER INSTALLATION

1. Pressure Gauge
2. Pop-off Valve (secondary safety relief valve)
3. Pressure Sensitive Regulating Unloader
4. Triplex Plunger Pump



Read all CAUTIONS and WARNINGS before commencing service or operation of any high-pressure system

SERVICING

Disassembly

1. Disconnect by-pass, discharge and inlet plumbing from unloader.
2. Remove unloader from pump.
3. Secure body of unloader in a vise with hex adjusting cap facing up.
4. Remove discharge fitting and o-ring, spring, check valve and o-ring.
5. Examine check valve and discharge fitting for wear, spring for wear or fatigue and o-rings for cuts or wear and replace as needed.

Note: While the discharge fitting is removed, inspect sealing area where the check valve makes contact within the internal body of the unloader for grooves, pitting and wear. If damage is found, stop the repair and replace with complete new unloader. If not, proceed with disassembly.

6. If supplied with a lock nut, the lock nut does not need to be removed. Turn lock nut down towards unloader body.
7. Remove hex adjusting cap by turning in a counterclockwise direction.
8. Remove spring and spring retainer.
9. Examine spring and spring retainer for scale build up, fatigue or wear and replace as needed.
10. Remove by-pass fitting with o-ring from bottom port.
11. Remove seat with o-ring from the male threaded side of by-pass fitting.
12. Examine seat for scale build up, scoring and wear and replace as needed. Examine o-ring for cuts or wear and replace as needed.
13. Removal of piston stem and valve/ball assembly requires the use of a small hex socket and screwdriver. Insert screwdriver from the top and place in slotted head of piston stem. Insert small hex socket into bottom port and secure valve/ball assembly. Unthread by turning in a counterclockwise direction.
14. Examine piston stem and valve/ball assembly for scale build up, scoring, pitting and wear and replace as needed. Examine o-rings and backup ring for cuts or wear and replace as needed.
15. Remove piston retainer with o-rings and backup rings by turning in a counterclockwise direction.
16. Examine piston retainer for wear. Examine o-rings and back-up-ring for cuts or wear and replace as needed.


Reassembly

1. Lubricate and install small body back-up-ring and then body o-ring into unloader body.
 2. Lubricate and install o-ring over threads of piston retainer.
 3. Carefully hand thread piston retainer with small diameter hole facing down into unloader body and tighten with a wrench.
 4. Lubricate and install o-ring over piston stem head and then backup-ring into groove of piston stem.
 5. Apply Loctite® 242® to the last few threads of the piston stem.
 6. Insert piston stem from the top through the piston retainer until seated.
 7. Using the same tools in removing the piston stem and valve/ball assembly, place valve/ball assembly into hex socket tool with ball surface facing down into socket. Place screwdriver tip into piston stem slotted head. Thread piston stem into valve/ball assembly.
 8. Place by-pass fitting on flat surface with male threads facing up.
 9. Lubricate and install o-ring onto seat. Press seat into by-pass fitting. Hand thread by-pass fitting into lower port of unloader body and tighten with wrench.
 10. Lubricate and install o-ring on discharge fitting.
 11. Insert spring into discharge filling, then insert check valve with small step end into spring. Hand thread into unloader body and tighten with wrench.
 12. Place spring retainer on top of piston stem.
 13. Place spring on to spring retainer.
 14. Thread hex adjusting cap onto piston retainer.
 15. Remove unloader from vise.
 16. Re-install unloader onto pump.
 17. Reconnect by-pass, discharge and inlet plumbing to unloader.
 18. Proceed to PRESSURE ADJUSTMENT.
- Loctite® and 242® are registered trademarks of the Henkel Corporation.


TROUBLE SHOOTING	
Unloader cycles	<ul style="list-style-type: none"> • Check for leak downstream of unloader. • Worn O-ring or check valve. • Air in system, poor connection. • O-ring in gun worn. • Insufficient flow through unloader.
Liquid leaking from bottom fitting	<ul style="list-style-type: none"> • O-ring for fitting cut or worn. • O-ring for seat cut or worn.
Liquid leaking from middle	<ul style="list-style-type: none"> • O-ring for piston cut or worn. • O-ring for piston stem cut or worn.
Unloader will not come up to pressure	<ul style="list-style-type: none"> • Not properly sized for system pressure. • Foreign material in unloader. Clean filter. • Piston stem O-rings worn. • Nozzle worn. • Insufficient flow to pump.
Extreme pressure spikes	<ul style="list-style-type: none"> • Adjusting nut turned completely into unloader. • Restricted by-pass or no by-pass. • System flow exceeds unloader rating.
Filtration	<ul style="list-style-type: none"> • Clean filter on regular schedule to avoid cavitation.

PRESSURE READING		
Approximate Pressure Reading at Gauge	Gauge Between Pump/Unloader	Gauge Between Unloader/Gun-Nozzle-Valve
System in operation (gun open)	system pressure	system pressure
System in by-pass (all guns, valves closed)	low pressure 0-150 PSI	system pressure +200 PSI

CUTAWAY



EXPLODED VIEW



PARTS LIST

ITEM	PN	MATL	DESCRIPTION	QTY
401	32088	NY	Handle, Adjusting, Black	1
402	33859	BB	Cap, Adjusting	1
403	33857	BB	Nut, Locking (M18x1)	1
404	33061	STZP	Screw, Set (M4x4)	1
408	33294	STZP	Spring (Silver)	1
410	32819	STZP	Spring, Guide	1
412	33860	S	Stem, Valve	1
414	—	PTFE	Back-up-Ring, Stem	1
415	—	NBR	O-Ring, Stem	1
425	33861	BB	Retainer, Piston	1
428	—	NBR	O-Ring, Retainer	1
429	—	NBR	O-Ring, Stem	1
430	—	PTFE	Back-up-Ring, Stem	1

ITEM	PN	MATL	DESCRIPTION	QTY
435	33853	SSS	Valve and Ball Assembly	1
436	33806	S	Seat w/NBR-O-Ring	1
439	—	NBR	O-Ring, By-pass Fitting - 85D	1
440	—	BB	Body, Valve	1
443	76736	BB	Valve, Check w/O-Ring	1
444	33843	S	Spring, Valve, Check	1
446	—	NBR	O-Ring, Discharge Fitting	1
455	33846	BB	Fitting, By-pass [3/8" BSP(F)]	1
460	33847	BB	Fitting, Discharge [3/8" BSP(F)]	1
468	76781	NBR	Kit, O-Ring (Incls: 414, 415, 428, 429, 430, 439, 446)	1
469	7224	—	Chemical Injector, Fixed (Not Shown)	1

Italics are optional items.

MATERIAL CODES (Not Part of Part Number): BB=Brass NBR=Medium Nitrile (Buna-N) NY=Nylon PTFE=Pure Polytetrafluoroethylene S=304SS SSS=416SS
STZP=Steel/Zinc Plated

Note: To mount injector on unloader, remove items 460, 446, 444 and 443. Insert items 444 and 443 into injector (item 469). Install new O-Ring (item 446) onto injector (item 469). Thread injector (item 469) into unloader. Discard fitting (item 460) and old O-Ring (item 446).

CAUTIONS AND WARNINGS

All High Pressure Systems require a primary pressure regulating device (i.e. regulator, unloader) and a secondary pressure relief device (i.e. pop-off valve, relief valve). Failure to install such relief devices could result in personal injury or damage to pump or property. Cat Pumps does not assume any liability or responsibility for the operation of a customer's high pressure system.

Read all CAUTIONS and WARNINGS before commencing service or operation of any high pressure system. The CAUTIONS and WARNINGS are included in each service manual and with each Accessory Data sheet. CAUTIONS and WARNINGS can also be viewed online at www.catpumps.com/cautions-warnings or can be requested directly from Cat Pumps.

WARRANTY

View the Limited Warranty on-line at www.catpumps.com/warranty.



CAT PUMPS

1681 - 94TH LANE N.E. MINNEAPOLIS, MN 55449-4324
PHONE (763) 780-5440 — FAX (763) 780-2958
e-mail: techsupport@catpumps.com
www.catpumps.com